



# SOLAR ROOFBLASTER™

## Installation Instructions



### Step 1: Cut Shingles

Starting 3 shingle rows down from the ridge, use a utility knife to cut two 8" on both sides and the top. Remove shingles and any nails/staples to get down to the roof deck.



### Step 4: Install Vent

Slide the ROOFblaster flashing up underneath the surrounding shingles so the vent is centered over the opening.



### Step 2: Cut 8" Opening

Cut an 8" square or 8" round opening in decking. Use the template on the back if needed.



### Step 5: Secure Vent

Secure the flashing on both sides with nails 2" down and 2" across from edge and a second nail 4" down and 2" across from edge. Repeat on the other side.



### Step 3: Vent Seam Down

Make sure you face the vent seam down slope.



### Step 6: High Wind

In high wind areas, also secure the front of the flashing down and apply sealant to cover fastener.

View installation videos at  
**SOLARBLASTERFANS.COM**