



# SOLAR RVOBLASTER™

## Installation Instructions



### Step 1: Remove Hood

Unscrew each of the screws on the RVO vent hood and place the screws in a safe place. Remove the hood and set it aside.



### Step 4: Retuck Screen

Retuck the screen around the lip of the RVO vent being sure to also tuck the wires downward for a more secure screen wrap.



### Step 2: Lift Up Screen

Carefully lift up the screen on both the top and bottom sides. Wear protective gloves as the screen has very sharp edges.



### Step 5: Reattach Hood

Reattach the hood using the screws from Step 1 making sure that the hood is firmly held by all four screws to the underlying brackets.



### Step 3: Insert Fan

Keeping the fan's wires toward the sky, insert the fan unit through the top side of the screen opening and snap both ends of the bracket into one of the grooves in the wall of the RVO vent.



### Step 6: Attach Panel

Take a spring steel clip and attach the sharper angled end under the lip of the solar panel and the other end under the hood lip. Then attach the top, right and left sides. Once all four clips are in place, tuck the wires underneath the vent.