## **Installation Instructions for Conex Containers**



# **SOLAR LIGHTBLASTER™**

Look over the full installation instructions below before starting.
We want your installation to be successful. Call if you have any questions:


480.747.7097

#### Materials Included:

- 16 roofing screws with rubber washer (a)
- 16 black rubber screw caps (b)
- EPDM foam gasket

#### **Tools Needed:**

- 1/4" driver (c) for the (a) screws
- · chop saw or sawzall
- · high quality roofing sealant





Step 1: Locate Install Location

Using the foam gasket, center it on top of a metal rib that is between rafters and hold the template while you



Step 4: Caulk Around the Opening

Using a quality roof sealant (not included), caulk completely around the opening in the metal roof.



Step 2: Trace Outline

Trace the innter edge of the gasket with a marker so you know where to cut. Be sure to press the gasket firmly along the metal rib while tracing.



Step 5: Attach the Foam Gasket

Place the foam gasket and carefully press it into place around the opening..



Step 3: Saw an Opening

Cut open the hole in the metal using a chop saw or sawzall.



Step 6: Caulk the Top of the Gasket

Using a quality roof sealant (not included), caulk completely around the top of the foam gasket.

## **Installation Instructions for Conex Containers**



## **SOLAR LIGHTBLASTER™**



Step 7: Install LightBlaster

Carefully place the LightBlaster on top of the foam gasket and press down firmly all around the flashing so it is sealed firmly.



Step 10: Enjoy Your Lit Up Container!

Please feel free to share a photo of your installed LightBlaster on our Facebook page or on Amazon. We'd love to see our products in use and it will help other customers.



Step 8: Attach LightBlaster with Screws

Using a drill, attach the LightBlaster using all 16 of supplied screws.

https://www.facebook.com/SolarBlaster



Step 9: Attach Screw Caps

Cover each of the exposed screws with the supplied screw caps (optional).

Solar Blaster Corporation © 2020 www.solarblasterfans.com Part No. SBLT-CNX-067